



# Pneumatic plugs for leakproof air-pressure (according to EN 1610)




- 1. PLUGY
- 2. PLUGSY
- 3. Adapter R1, R2
- 4. Inflation hose  
with claw /quick action  
coupling/ to fill the pipe
- 5. Measuring hose  
with nipple and gauge
- 6. Inflation hose
- 7. Single fitting controller
- 8. Pressure regulator
- 9. Compressed air cylinders



## A Adapter R 1

- 1. Adaptor
- 2. Air inlet
- 3. Hose



## B Adapter R 2

- 1. Adaptor
- 2. Air inlet
- 3. Claw coupling
- 4. Hose